

# Driving Success

## What is PathSpot Measuring? What are our goals?

### Rewash Rate



Contamination happens! Our World is a dirty place. Every time there is a contamination detected, it's required that you rewash your hands and scan again. Once you get a pass, the contamination scan is overwritten with a passing scan.

Rewash Rate is the measure of handwashes corrected by employees, who's first scan was contaminated.

Our goal should always be to have a 100% rewash rate.

### Time between Handwashes.



Handwashing is important. It's important when you start your shift, and before you leave to go home. It's also important throughout your shift.

Handwashes should happen once an hour and even more frequently at times within your department.